

Lime Concrete Flooring Jointing and Pointing Mortar for Slabs

The following details are given for information purposes only. Final dosages and application should be checked with our technicians

1. Ingredients

NHL5 at 1:2.5 with sharp concreting sand $\frac{1}{2}$ " (6mm) to #200 (0.075mm) for joints $\frac{1}{2}$ " to $\frac{3}{8}$ " (6-10mm wide). Use fine sharp sand #16 (1.18mm) to #200 (0.075mm) for joints up to 6mm. Avoid saturated sands.

2. Mixing

Mix ingredients dry to achieve a uniform color. Add: the minimum of water, the mortar should be quite dry.

3. Placing

Dampen the joints of the slabs taking care not to wet the surface of the slabs, brush mix into joints and compact with pointing key, clean all excess from slabs and lightly dampen joints with clean water several times over a period of approximately two hours depending on weather conditions.

4. Curing

Never lay on a frosted or exceedingly hot surface. Protect from extreme heat, freezing, excessive wind, strong direct sunlight and rain. Ambient temperature range should be 40°F to 85°F with low to average humidity.

5. Protection

Foot traffic should be avoided for 48 hours depending on the weather. Provide walkways with boards during and after placing to distribute any foot traffic/loading.